


1. Instalación del driver de Windows


Advertencia:

Bajo diferentes sistemas operativos la pantalla puede tener ciertas diferencias. Por favor proceda acorde a los tips, Tome como ejemplo la instalación SAT15TUS (Windows 7).


- (1) Doble click Windows Driver.
- (2) Seleccione el lenguaje, en este ejemplo "English" y de click en "OK".




- (3) Click "Siguiente".



(5) Click "Siguiente"



(6) Seleccione el tipo de Puerto (USBxxx es para Puerto USB, COMx es para puerto serial, LPTx es para puerto paralelo). Seleccione el tipo de driver, puerto, ejemplo “COM1” como puerto. Dé click en “Configurar Puerto”.



NOTE: If printer is already connected with computer by USB port, it only needs to click “Install”, then it will be installed automatically. Otherwise, proceed to the next step.

(3)Click"Finish". POS printer driver is installed successfully.



(3)After installation, the icon will be found in "Start"→"Devices and Printers".



NOTE: If you already installed the driver (No matter what kind of port), when you connect the printer with computer, it will create a USB port automatically.